

User Replaceable Items effective 12/01/2005

PowerLite 735c

<u>DESCRIPTION</u>	<u>PART NUMBER</u>
AC Power Cable	207 1477
RCA AV Cable	206 8507
Computer Cable (VGA Cable)	207 1748
USB Mouse Cable	110 1569
Wireless LAN Card (802.11b)	208 1852
EasyMP Software CD-ROM for the PL-735c	302 0417
Lamp (V13H010L18)	H010L18 (600 7283)
Remote Control (PL735c)	600 8203
Lens Cap with String	110 8344
User's Manual	CPD-15675
Navy Blue Carrying Case with handle and shoulder strap (outside compartment for cables)	1273485

Order user replaceable parts from an [Epson authorized parts distributor](#).

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the “Help me find...” tool in the right column of the [Epson Support](#) home page.